


GAS STOVE USER MANUAL

Please read before starting.
There are important explanations for you.

E AGO-360 E AGO-460 E AGO-660 E AGO-860
E AGO-1060



CONTENT

Technical Information Tables	3-4-5-6
General warnings and security measures	7-8
Setup	9
Operation and use.....	10
Basic and technical specifications	11-12-13
Gas exchange	14-15
Cleaning and maintenance	17
Spare Parts List.....	18



If you want to dispose of the product, it is the social responsibility of individuals to deliver it to valid collection points. In this way, you help prevent possible negative consequences for the environment and human health by ensuring that the product is destroyed correctly. Recycling materials will help conserve natural resources.



The packaging materials of the product are manufactured from recyclable materials in accordance with national environmental legislation. Do not dispose of packaging materials with household waste or other waste. Take these materials to recycling points designated by local authorities.

Quality controls were carried out in accordance with the norms of CE, ISO 9001-en standards.

GENERAL INFORMATION

Model	E AGO-360	E AGO-460	E AGO-660
Product dimensions (cm)	30x60x30	40x60x30	60x60x30
Net weight (kg)			
Stove Pleyt diameter (Ø)	Ø180	Ø180	Ø180

GENERAL INFORMATION

Model	E AGO-860	E AGO-1060	-
Product dimensions (cm)	80x60x30	100x60x30	-
Net weight (kg)			-
Stove Pleyt diameter (Ø)	Ø180	Ø180	-

Technical Information Tables

Country Of Arrival	Category	Gas	
FR-BE	I12E+3+	2E+	G20
		3+	G30-G31
ES-IE-IT-GB-PT	I12H3+	2H	G20
		3+	G30-G31
AT-CH	I12H3B/P	2H	G20
		3B/P	G30
DE-LU	I12E3B/P	2E	G20
		3B/P	G30
AL-BA-BG-DK-EE-FI-HR-LT-LV-MK-NO-RO-SE-SI-UA-CZ-GR-SK-TR	I12H3B/P	2H	G20
		3B/P	G30
RS*-ME*IR*-AR*-GE*-RU*-UA*-DZ*-SA*-NG*-ZA*-MA*-UZ*-LY*-LZ*LB*-SY*-JO*	I12H3B/P	2H	G20
		3B/P	G30
NL	I12L3B/P	2L	G25
		3B/P	G30
PL	I12E3B/P	2E	G20
		3B/P	G30
HU	I12H3B/P	2H	G20
		3B/P	G30
IS-CY-MT	I3B/P	3B/P	G30




-Do not forget to adjust the bypass after changing the gas.

Technical Information Tables

Gas Pressure			Adjusted Gas
→	20-25 mbar	NG	G20-25 mbar
→	28-30/37 mbar	LPG	G30-28-30/37 mbar
→	20 mbar	NG	G20-20 mbar
→	28-30/37 mbar	LPG	G30-28-30/37 mbar
→	20 mbar	NG	G20-20 mbar
→	50 mbar	LPG	G30-50 mbar
→	20 mbar	NG	G20-20 mbar
→	50 mbar	LPG	G30-50 mbar
→	20 mbar	NG	G20-20 mbar
→	28-30 mbar	LPG	G30-30 mbar
→	20 mbar	NG	G20-20 mbar
→	28-30 mbar	LPG	G30-30 mbar
→	25 mbar	NG	G25-25 mbar
→	28-30 mbar	LPG	G30-30 mbar
→	20 mbar	NG	G20-20 mbar
→	37 mbar	LPG	G31-37 mbar
→	25 mbar	NG	G20-25 mbar
→	30 mbar	LPG	G30-30 mbar
→	28-30 mbar	LPG	G30-30 mbar

Adjusted gas
mbar



Remove the set Gas Information plate on the device. Insert the information plates that come with the device that correspond to your country.



-According to the model of the device for gas exchange, you can see which injector to use from the table in the user's guide of your product. See also (Page 6)

Technical Information Tables

E AGO-360								
	NG			LPG				
Gas Pressure	G20-20 mbar	G20-25 mbar	G25-25 mbar	G30-29 mbar	G30 (28-30/37)	G30 37 mbar	G30 50 mbar	G31 37 mbar
Pilot injector (D)								
Burner injector								
Amount of heat (KW) (Hi)								
Gas consumption m3 / h								
Gas consumption g / h								
E AGO-460								
	NG			LPG				
Gas Pressure	G20-20 mbar	G20-25 mbar	G25-25 mbar	G30-29 mbar	G30 (28-30/37)	G30 37 mbar	G30 50 mbar	G31 37 mbar
Pilot injector (D)								
Burner injector								
Amount of heat (KW) (Hi)								
Gas consumption m3 / h								
Gas consumption g / h								
E AGO-660								
	NG			LPG				
Gas Pressure	G20-20 mbar	G20-25 mbar	G25-25 mbar	G30-29 mbar	G30 (28-30/37)	G30 37 mbar	G30 50 mbar	G31 37 mbar
Pilot injector (D)								
Burner injector								
Amount of heat (KW) (Hi)								
Gas consumption m3 / h								
Gas consumption g / h								
E AGO-860								
	NG			LPG				
Gas Pressure	G20-20 mbar	G20-25 mbar	G25-25 mbar	G30-29 mbar	G30 (28-30/37)	G30 37 mbar	G30 50 mbar	G31 37 mbar
Pilot injector (D)								
Burner injector								
Amount of heat (KW) (Hi)								
Gas consumption m3 / h								
Gas consumption g / h								
E AGO-1060								
	NG			LPG				
Gas Pressure	G20-20 mbar	G20-25 mbar	G25-25 mbar	G30-29 mbar	G30 (28-30/37)	G30 37 mbar	G30 50 mbar	G31 37 mbar
Pilot injector (D)								
Burner injector								
Amount of heat (KW) (Hi)								
Gas consumption m3 / h								
Gas consumption g / h								

General warnings and security measures

Dear customer, we wish you to use your product in the best way, which is manufactured by undergoing careful and detailed quality checks. We strongly recommend that you read the full user guide before using the product. This guide will help you use the product quickly and safely.



The following safety instructions will help protect you from the risk of personal injury or damage to your product. If these instructions are not followed, the product will not be covered by the warranty and no responsibility for human health will be accepted.

- * Make sure that flammable materials that may cause fire are not located near the device.
- * Keep your device in a dry environment and air it well. Use a hood to remove steam and smoke from cooking.
- * Do not close the top perforated sheet of the device and keep it clean.
- * Installation and maintenance of the device should be carried out only by qualified personnel. Contact an authorized person authorized by the manufacturer. Otherwise, your device will be excluded from the warranty.
- * Replace the damaged parts of the device with the original spare parts. The manufacturer undertakes that the device can be used safely only when these parts are used.
- * Children and uninformed persons should not be allowed to use the device.
- * Keep the device under constant control while it is running.
- * Turn off the device if it malfunctions or malfunctions.
- * The device must have a ground line and a leakage current relay.
- Sodium hypochlorite(bleach), hydrochloric or muriatic acid, etc.to clean the device. do not use products that contain (even diluted). Do not use metal tools to clean rust. First wipe with a damp cloth and then dry.
- * Do not store gasoline or flammable liquids near this device.
- * Do not allow oil to come into contact with plastic parts.
- * Do not clean the device directly with water jets or water vapor.
- * Do not allow dirt, oil, food or other waste to form sediment in the device, do regular daily and weekly cleaning.
- * Before connecting the device, check that the device settings are compatible with the local gas distribution network (gas pressure and LPG, NG). You can find the values from the label on the device or from the table inside the grid.
- * Make the gas connection of your device close to the LPG tube or natural gas valve and is waterproof. (max. 2mt)
- * The maximum gas pressure that can be applied when the device is running is 50 mbar. The injectors that come with the device and the standards in your country of destination should be taken into account.
- At pressure above 50 mbar, there is a risk of gas leakage. In the event of such a situation, your device may deteriorate and fall outside the scope of the warranty.
- * The device is recommended to be checked by an authorized person. Contact the authorized technical service to maintain your device at least once a year.

General warnings and security measures



- Always follow applicable safety instructions.
- Keep the user's guide in a place that you can easily access for future use, understanding its importance, and do not lose it.
- The manufacturer reserves the right to make changes to the product. It clearly states the differences between the models.

Contact your authorized dealer if you have any problems.



A warning sign indicating that caution is required for safe use.



It is a warning sign against fire, explosion and death caused by lack of safety measures.



Extreme temperature and this is a warning sign to act according to the environment.

- Stainless steel material is used in the device.
- Your device is manufactured for use in restaurants, restaurants, fastfoods, canteens, tourist facilities, cafes, hotels and other environments where accommodation is made.

If you smell gas.



- * First, calm down; do not panic.
- * Turn off the device's gas tap.
- * Burning materials (candles, lighters, etc.) extinguish immediately.
- * Open doors and windows to air.
- * Do not attempt to burn any device.
- * Do not touch any power button or socket in case of danger.
- * Do not use the doorbell.
- * Do not light matches or lighters in the hazardous area .
- * Close the gas valve outside the building.



- Always install the product to an Authorized Service. The manufacturer is not responsible for damage to the product caused by transactions performed by unauthorized persons.

- Before assembly, please note that the connection lines are made correctly and completely.





- Before starting the device for the first time, remove the protective nylon on the device, first wipe it with a damp and then dry cloth.

- Place under the hood to remove smoke and odor that may occur during the cooking process.

- Children and uninformed people should not be allowed to use the device.


- See that the device is in balance by measuring it with water balance.



Make sure that the set six pins sit in the slot.

Leave a sufficient distance between the device and the walls.

If the set six countertops will not be used, install the feet coming out of the box.




- You can turn the heat slider clockwise and adjust it to a low temperature or normal temperature.
- You can turn off the device by moving it to the “●” position to turn it off.




- * The device is made of stainless steel.
- * The device can work with both LPG (liquefied petroleum gas) and NG (natural gas).
- If the Stove goes out in the device, the leaking gas is stopped by a safety valve.
- * With the help of the waste oil reservoir, the oil in the device can be easily discharged.

Basic and technical specifications




PRODUCT CODE	A	B	C	D	E
E AGO-360	300 mm	600 mm	300 mm	35 mm	28 mm
E AGO-460	400 mm	600 mm	300 mm	35 mm	28 mm

Basic and technical specifications




PRODUCT CODE	A	B	C	D	E
E AGO-660	600 mm	600 mm	300 mm	35 mm	28 mm
E AGO-860	800 mm	600 mm	300 mm	35 mm	28 mm

Basic and technical specifications




PRODUCT CODE	A	B	C	D	E
E AGO-1060	1000 mm	600 mm	300 mm	35 mm	28 mm




- Gas pressure is written on the information label on the device.
- It is absolutely not recommended to exclude the information on it. Otherwise, your device is out of warranty.
- It is manufactured with LPG and NG (natural gas). The gas connection pipe is R1 / 2".
- Gas exchange with LPG injector or NG injector can be done as in Burner injector change table.
- After looking at the gas table for change, injector diameters should also be taken into account according to the gas pressure.
- When checking the device, make sure that the gas buttons and the tube (or natural gas line) are in the closed position. Check for gas leakage with soap-foamed water or gas leak detector.
- If there is a gas leak, foaming will occur in the soapy part. In the control with the detector, the control detector will give a signal. If the device signals, consult your authorized dealer.
- Never use fire when checking for gas leaks.
- Make sure that another regulator is used other than the regulator recommended for the device (especially when using an LPG tube).

Injector replacement information label replacement



Note: depending on the gas connection of the place where you are operating the device, you can use the appropriate injectors. These injectors are supplied with the device.



Adjusted gas mbar




Remove the set Gas Information plate on the device. Insert the information plates that come with the device that correspond to your country. (See fig. Page 5)




- Your product is adjusted according to the gas category in the country of Destination.
- Change the injectors according to the gas category of your country when replacing the injector. See table on Page 5.

Bypass Tuning



For NG
turn one
full turn
counter-
clockwise.

Bypass Tuning




For LPG
turn clock-
wise to the
end.


What you will pay attention to before cleaning and maintenance.




- Wait for the device to cool down.
- Wipe the device with a cloth soaked in warm and soapy water.
- Acid-containing chemicals should not be used during cleaning on the stainless surface of the device.
- Never clean your device with pressurized water or pressurized steam. Otherwise, you may cause a malfunction.
- Do not leak water through the vents while cleaning the device.
- Notify the Authorized Service if a dangerous situation occurs on the device.
- Drain at regular intervals with the help of a waste drain fountain.
- Clean the waste accumulated in the cooking chamber of the device.
- If the device is not to be used for a long time, the surfaces should be covered with a thin layer of Vaseline.
- For cleaning stainless steel, do not use General steel abrasives, scrubbing pads, brushes, or detergent products containing abrasives.




Take the grates on the Stove.




Remove Stove begs.




Wipe the surfaces that do not flake with a damp cloth.



Clean the Stove begs with a brush.



You can clean the grills on the Stove with a brush.




After cleaning, try burning it.



- Before cleaning, make sure that your device is cold.
- Do not use abrasive chemical cleaners or steel cleaning materials when cleaning. (If necessary, use a chemical cleaner)

Spare Parts List



NO	TRACK NO	EXPLANATION
1	P062840	Grid (AGO-360)
1	P062832	Grid (AGO-460-860)
1	P062840	Grid (AGO-660)
1	P071242	Grid (AGO-1060)
2	P005265	6 KW Beg
3	P005266	6.5 KW Beg slot
4	P000221	1/2" Zinc Alloy Elbow
5	P068098	Bakelite Button
6	P009963	Gas Flexi Tubing

NO	TRACK NO	EXPLANATION
7	P013443	Injector
8	P073499	Thermokupul
9	P011060	Ø 10 gas flexi pipe
10	P014704	Injector ø1. 20
11	P069599	Pilot Gas Pipe
12	P002927	Gas tap
13	P008702	Gas Stove Torsion
14	P001184	Gas burner elbow